

ASSEMBLY INSTRUCTIONS

TYCHUS SIXTH SCALE FIGURE

ATTENTION: PLEASE USE CAUTION DURING ASSEMBLY


FOR FURTHER ASSISTANCE:

CALL US (WITHIN U.S.): 1-855-SIDESHOW


CALL US (OUTSIDE U.S.): 1-805-214-2157




Included: Articulated figure body with highly detailed articulated armor, removable helmet with retractable blast shield visor, angry portrait, cigar chompin' portrait, C-14 impaler gauss rifle, bayonet attachment, two (2) terran flash grenades, torso lights, light-up engine vents, extendable illuminated power cells & helmet illumination.




Power cell chest pullouts (on both sides). Power button for light-up elements in the chest and engine vents located on back panel.




Light-up components: Remove screws from the two back panel battery compartments (figure takes four (4) AAA batteries).





Double shield helmet silver. Blast shield does not fully close.




To remove helmet slightly compress both sides at the base and lift off (be careful of mic).



Insert bayonet into C-14 Impaler Gauss Rifle, light-up power button located on top handle, batteries located in cartridge (rifle takes two LR44 Batteries). Wrist extends for rifle posing.



Re-insert any misplaced pipes back into elbow/forearm area. Reattach any unattached pipes onto the ball joints in the waist/lower back area.



Please note: be mindful of limited knee and waist articulation. Please use care when posing.



SIDESHOW.COM